


ALUMINUM SUBLIMATION INSERT PRODUCTS

SILM50, GLDM50, BRM50, RMC1, SMC2, SGL10, BKC21, BKC22, BK23, PRS1, PRR2, PRH3, PRK4, PRG4, RRG4, LNB16, LPP3, LSW9, LLW10, LWL11, PLK3, PLK5

Settings

- **Time:** 45 seconds
- **Temperature:** 356° F
- **Pressure:** Moderate



Fabrication Process

- Remove the protective film from the aluminum insert.
- Affix the transfer to the insert using heat tape.
- Place sacrificial paper on the heat press bed.
- Set the insert on the bed with the transfer paper side up.
- Place additional sheet of sacrificial paper over the insert.
- Press the insert.

Note:

Insert will be extremely hot. Use of gloves or a cloth is recommended for removal of finished insert from press.