

## MDF HARDWOOD EARRINGS

EARROUND10, EARTEARDROP10, EARDIAMOND10

### Settings

- **Time:** 50 – 60 seconds
- **Temperature:** 360-390°F
- **Pressure:** Moderate (Press one side at a time)

### Fabrication Process

- Preheat the heat press to a temperature between 360-390°F.
- Print your graphic on the sublimation transfer paper.
- Design Tip: Use the product template to place and align your graphic to fit the earring blanks. Place the graphic within the bleed line boundaries of the template to ensure an edge-to-edge print on the earring blanks.
- Place the earring blanks onto the printed graphics. Secure blanks with heat tape.
  - Tip: For best results, place heat tape close to the edges of the earring. Avoid taping across the earring.
- Place a piece of blowout paper on the heat press platen.
- Place the earring blanks with attached transfer on top of the blowout paper with transfer paper on top.
- Adjust press pressure to medium. Close and press for allotted time.
- When finished, open press and remove earrings. Remove the transfer paper and discard.
- It is recommended to press only one side of the earrings at a time. Repeat pressing steps for the second side of the earrings.

### Note:

The above recommendations are offered as a safe starting point. Minor adjustments may be needed to achieve optimal results.

