

3" CERAMIC ORNAMENTS – SUBSQU, SUBOCT, SUBFLO, SUBCIR, SUBCIR2

These high quality, easy care ceramic ornaments offer a personal touch to your holiday decorating and gift giving.

Settings

- **Time:** 150-170 seconds
- **Temperature:** 390° - 400° F
- **Pressure:** Light

Fabrication Process

- Place the ornament down on top of the image on the sublimation transfer paper. Secure the ornament to the paper with heat tape.
- Place a Nomex Felt Pad on the bottom platen of the heat press. Place a piece of blowout paper on top of the felt pad.
- Place the transfer sheet with attached ceramic ornament onto the blowout paper with transfer paper facing down (transfer paper should be below the ornament).
- Place a sheet of blowout paper on top of the ornament.
- Adjust the press pressure to light.
- Close the press for recommended time.
- When finished, open the press and remove the top blowout paper, then using a heat glove, carefully remove the ornament from the press. Remove the transfer paper from the ornament and discard.
- Set ornament aside to cool.
- Repeat all steps to sublimate the second side.

Note:

Settings are offered as a safe starting point. Minor adjustments may be needed to achieve optimal results.