

POKER CHIP JIG

PC700J

General Instructions

- After aligning your artwork in the template, place the jig on a piece of blowout paper on your heat press.
- Place the blank poker chips in the cutout holes of the jig.
- Print the sublimation transfer. Align the transfer paper over the jig and secure with heat tape.
- Press the poker chips for the allotted time (See PC700 Tech Tip).

Tip:

- It may be necessary to secure the jig down to the heat press platen as the jig may try to warp slightly after several press cycles.
- For longer production runs, tape the jig down to a scrap piece of engraving aluminum to help preserve flatness of the jig more effectively.
- If pressing the second side of the poker chips, make sure to replace the blowout paper underneath the chips with a new piece before pressing the next set of new blank chips.