

## SUBLIMATABLE SANDALS

SUBS37, SUBS38, SUBS41, SUBS42

### Settings

- **Time:** 120 seconds
- **Temperature:** 356° F
- **Pressure:** Moderate

### Fabrication Process

- Pre-press the flap of the sandal so that it is flat during this sublimation process. Butt the sole of the sandal against the edge of the heat press to ensure the flap is the only piece under the platen.
- Attach transfer to the sandal using clear heat tape.
- Place sacrificial paper on press bed.
- Set the flap of the sandal over the paper towards the edge of the bed. It is recommended to butt the sole of the sandal against the edge of the press to ensure the flap is the only piece under the platen.
- Hold the sole of the sandal in place while placing another sacrificial sheet of paper over the sandal flap.
- Lower the heat platen onto the flap of the sandal to start the sublimation process. You will need to hold the sole to ensure the sandal does not move. Once under pressure you may let go of the sole.

### Note:

Product will be extremely hot. Use of gloves or a cloth is recommended for removal of finished product from press.