TECH TIP

WHITE STAINLESS COFFEE CUP 10 oz.

SSCW10

Settings

• Time: 60 seconds

Temperature: 375° F

Pressure: Light



Tools & Accessories

- Mug Press
- Heat Tape

Fabrication Process

- Affix the transfer to the cup using heat tape.
- Place sacrificial paper over the transfer. Place in mug press.
- After appropriate cure time, remove from oven and set aside to cool. Water bath can be used for faster cooling.

Note

• Use caution when removing from oven. Product will be extremely hot.



