

WOODEN WINE CASE

WC01

Settings

- **Time:** 110 seconds
- **Temperature:** 374° F
- **Pressure:** Moderate

Tools & Accessories

- Heat Tape
- Sacrificial Paper
- Heavy Object



Fabrication Process

- Remove the protective film from the hardboard insert.
- Affix the transfer to the insert using heat tape.
- Place sacrificial paper on the heat press bed.
- Set the insert on the bed with the transfer paper side up.
- Place additional sheet of sacrificial paper over the insert.
- Press the insert.
- Remove insert from press & set aside to cool with heavy object on top to ensure the piece remains flat.

Note:

Insert will be extremely hot. Use of gloves or a cloth is recommended for removal of finished insert from press.