

Sublimation Visor White Tech Tips



SUBLIMATION VISOR WHITE – DTF

ITEM # SUBVISOR



GENERAL DTF TRANSFER PROCESS

Recommended Equipment & Accessories

- DTF Printer
- DTF Printer paper (see your printer's manufacturer for recommendations)
- DTF powder
- Standard Flat Heat Press- Swing-away style press recommended
- Heat Tape
- Teflon sheet
- Finishing Sheet
- Heat gloves

Recommended Settings	
<i>Refer to the DTF Paper Instructions for best results.</i>	
Time	20-30 seconds
Temperature	320° F
Pressure	Medium-High
Peeling	Cold Peel

General DTF Instructions

- **Follow the DTF Paper Instructions for best results.**
- Print artwork on DTF Printer
- Apply DTF adhesive powder to artwork and cure according to DTF powder application instructions.
- Adjust press pressure to medium/high
- Preheat the heat press to 320°F or temperature specified per paper instructions.
- Print and place transfer sheet face down onto the surface of the product blank. Secure transfer with heat tape.
- Place the product blank with attached transfer sheet onto the heat press platen with the transfer paper on top.
- Place a piece of Teflon on top of the transfer paper.
- Close and press for the recommended time.
- When finished, open the press and remove the Teflon sheet.
- Using heat gloves, remove the product from the press.
- Peel the transfer paper off the surface of the product while the product surface is cool to the touch.

Tips and Tricks

- For best image placement, utilize the product template found on the product page on JPPlus.com.

Troubleshooting

- The image did not completely transfer to the product.
 - Slightly increase the press pressure.
 - The product may still be too warm when peeled. Wait a little more time before peeling the transfer paper.
- Ensure that the DTF paper used is compatible with the product material.

Templates and Images

- Visit jpplus.com to find the product page for this item. The product template may be found under the Tech Docs and Downloads area of the page.
-

To order more of this product, see similar products and much more, please visit jpplus.com.

For additional product support and troubleshooting, please contact JPPlus Advanced Support Team:

- Phone: 419-500-4877
- Email: ast@jpplus.com
- Schedule an appointment: <https://jpplusadvancedsupport.setmore.com/>