

PET LEASH w/ WHITE PATCH – PLW1

Settings

- **Time:** 50 seconds
- **Temperature:** 385 - 390° F
- **Pressure:** Moderate

Fabrication Process

- Place the white patch of the pet leash onto the image on the transfer paper and secure leash to paper using heat tape.
- Place blowout paper on the heat press platen.
- Place the transfer paper with attached leash onto the blowout paper with the transfer on top.
- Close heat press for allotted time.
- When finished, open press and remove leash.

Note: Vapor foam can also be used to press leash. When using Vapor foam, adjust press pressure to very light so that the Vapor foam pad compresses to approx. half the normal thickness of the pad.